



6907 FM 1488 • Magnolia, Texas 77354
PO Box 1247 • Magnolia, Texas 77355-1247
281.356.1257 • 281.356.1259 fax
800.869.0976



FILTER UNITS WITH MASTERFIL FILTER PADS

BASIC OPERATION

1. SET UP FILTER MACHINE WITH A MASTERFIL PAD.
2. AFTER LUNCH, FILTER ALL FRYERS.
3. FILTER THE CLEANEST OR NEWEST FRYER FIRST OR FOLLOW YOUR COMPANY'S FILTERING PROTOCOL.
4. USE 1 - 8OZ. CUP OF MAGNASOL FILTER POWDER FOR EACH FRYER.
5. DRAIN OIL FROM FRYER INTO TANK & USE DISCHARGE HOSE TO WASH DEBRIS OUT OF FRYER. AFTER SCRAPING & WASHING ALL DEBRIS OUT CLOSE DRAIN & REFILL FRYER WITH CLEAN OIL.
6. FILTER EACH FRYER APPROXIMATELY 5-7 MINUTES. NO NEED TO POLISH OR RECIRCULATE OIL.

TO CLEAN DAILY

1. REMOVE FILTER ASSEMBLY BY STANDPIPE. HOLD OVER TRASH CAN & SCRAPE OFF ALL FOOD DEBRIS & SET FILTER PAD ASIDE. DO NOT DISASSEMBLE FILTER PAD, **DO NOT WASH WITH WATER.**
2. SCRAPE OUT FILTER TANK: RINSE TANK WITH WATER & DRY WITH TOWEL & SET MASTERFIL FILTER PAD BACK INTO TANK.
3. SYSTEM IS READY FOR NIGHT SHIFT.
4. NIGHT SHIFT SHOULD REPEAT STEPS 1 AND 2.
5. **CHANGE THE MASTERFIL PAD WHEN YOU CHANGE YOUR OIL, IF YOU ARE ON A ROTATION SYSTEM CHANGE MASTERFIL EVERY 7 DAYS.**