

Masterfil Inc

6907 FM 1488 MAGNOLIA TX 77354
281-356-1258 | 281-356-1259 FAX
permafilinc@yahoo.com

WARNING

Filter and Fryer parts may be 'HOT'
Take proper precautions to avoid possible burns.

FOR ABSOLUTE FILTRATION & MAXIMUM FLOW RATE
WE RECOMMEND YOU CHANGE YOUR FILTERS EVERY 7 DAYS
OR EVERY OIL CHANGE

INSTRUCTIONS TO REMOVE & REPLACE MASTERFIL® FILTERS



FIG 1

Disconnect suction hose from filter assembly by Quick Disconnect & remove filter assembly out of filter pan.




FIG 2

Scrape off all debris into the trash & unscrew stand pipe from filter.



FIG 3

Remove SS closure clip by lifting off one side in a hinge motion until off of filter.



FIG 4

Remove Insert from dirty filter and wash insert with hot water and dry thoroughly. Place clean and dry insert into new MASTERFIL® filter envelope.



FIG 5

Fold both sides over top of insert & place SS closure clip on one side – hinge over & firmly press clip all the way down to secure and seal filter. Screw suction pipe assembly on to filter assembly tightly. The filter is now ready to go back into the clean filter pan. Re-connect suction pipe assembly and the system is ready.

MASTERFIL® patent pending